

## HOW TO MOUNT DILAD™ SCREENS

To apply the adhesive-backed DILAD™ screens to windows, glass, acrylic or polycarbonate substrates, have the following items ready to use:

- DILAD™ series cut sheet to size
  - Spray bottle with water
  - Rubber-blade squeegee
  - Dry, soft cloth
  - Tape to mark the boundaries of the DILAD™ screen if it is smaller than the substrate
1. Thoroughly clean the glass or plastic substrate of dirt, dust or oils using mild detergent if necessary and squeegee the excess soap/water from the substrate.
  2. Use the tape to mark the area that the screen will be applied (if the screen is smaller than the substrate.)
  3. Peel the release film from the DILAD™ screen half way back and spray the adhesive-side of the screen and the surface of the substrate with water.
  4. Place the DILAD™ screen carefully on the substrate while aligning the edges to the tape.
  5. Remove the water and any air bubbles with the squeegee blade by gently squeezing the water from the center of the screen toward the edges.  
**NOTE:** The squeegee may glide more smoothly over the top of the screen if it is also sprayed with water.
  6. Repeat Steps 3 to 5 for the other half of the screen.  
**NOTE:** Make sure to peel the release film evenly from both corners to prevent the screen from creasing or folding over on itself.
  7. Remove the excess water with a dry, soft cloth.
  8. Remove the tape.
  9. For "G" types, remove protective cover after mounting.